


APPENDIX A - CONNECTIONS WORK CENTERS

The information listed below explains the distance between the legs of each Connections Work Center giving the amount of leg room under the table. Also listed is whether or not the table can accept a keyboard drawer and how many.



Model	Distance between legs	Can it accept keyboard drawer?	If so, how many?
3514-GM_	37" (940mm)	YES	1
3515-GM_	37" (940mm)	YES	1
3517-GM_	31" (787mm)	YES	1
3518-GM_	43" (1092mm)	YES	1
3519-GM_	55" (1397mm)	YES	2
3520-GM_	31" (787mm)	YES	1
3521-GM_	31" (787mm)	YES	1
3522-GM_	43" (1092mm)	YES	1
3523-GM_	43" (1092mm)	YES	1
3524-GM_	55" (1397mm)	YES	2
3525-GM_	67" (1701mm)	YES	2
3526-GM_	67" (1701mm)	YES	2
3543-GM_	31" (787mm)	YES	1
3544-GM_	31" (787mm)	YES	1
3545-GM_	43" (1092mm)	YES	1
3546-GM_	43" (1092mm)	YES	1
3547-GM_	55" (1397mm)	YES	2
3549-GM_	55" (1397mm)	YES	2
3560-GM_	55" (1397mm)	YES	2
3561-GM_	55" (1397mm)	YES	2
3564-GM_	67" (1701mm)	YES	2
3565-GM_	67" (1701mm)	YES	2
3566-GM_	67" (1701mm)	YES	2
3567-GM_	67" (1701mm)	YES	2
3569-GM_	31" (787mm)	YES	1
3570-GM_	43" (1092mm)	YES	1
3576-GM_	25" (635mm)	NO	0
3577-GM_	25" (635mm)	NO	0