




# BRETFORD

## PRESENTATION ENVIRONMENTS®

### TransTable®

### Hinge Pin Assembly



Align hinge barrels on pedestals with hinge barrels on frame uprights, as shown. Drive pins into barrels with a hammer, with the flat end up.

**Bretford**  
11000 Seymour Avenue  
Franklin Park, IL 60131  
TEL: 847.678.2545  
800.521.9614  
FAX: 847.678.0852  
800.343.1779

**Bretford Ltd.**  
Technology House  
7 Lake End Court, Taplow  
Bucks SL6 0JQ England  
TEL: 01628 603558  
FAX: 01628 604923

[www.bretford.com](http://www.bretford.com)

Part #031-3692  
Rev. 10.21.03 CH

Presentation Environments® is a registered trademark of Bretford Manufacturing Inc.